



## The New OzE Wand

### OzEWand (ZEBEX 1050) Operations

- **To clear**
  - Press and hold left orange button (or both orange buttons) then press left blue button for at least 4 beeps
- **To Sync camera to OzEWand**
  - Take picture of slate and press ANY blue button at the same time (no need for sync tray anymore!)
- **To read barcode**
  - Hold scanner flat against barcode or no more than 2 inches away
    - Holding against the barcode works good outside in the sunlight!
    - You can use either or both orange buttons to scan.
- **To download**
  - On OzEDownloader program select the ZEBEX Z 1050 option
    - Make sure you use the cable provided with the ZEBEX
      - Looks like the one for the Symbol but they are different